





ELMA-LE26



PL INSTRUKCJA MONTAŻU
INSTRUKCJA OBSŁUGI

GB ASSEMBLY INSTRUCTIONS
INSTRUCTION MANUAL

D MONTAGEANLEITUNG
BEDIENUNGSANLEITUNG

NL HANDLEIDING VOOR DE MONTAGE
GEBRUIKSAANWIJZING

TR MONTAJ TALIMATI
KULLANIM KLAVUZU

RU ИНСТРУКЦИЯ ПО УСТАНОВКЕ
РУКОВОДСТВО ПО ЭКСПЛУАТАЦИИ

RO INSTRUCTIUNI DE INSTALARE
INSTRUCTIUNI DE UTILIZARE


IT ISTRUZIONI DI MONTAGGIO
MANUALE DI ISTRUZIONI


FR NOTICE DE MONTAGE
MANUEL INSTRUCTIONS



SK MONTAZNY NAVOD
NAVOD NA POUZITIE


HU SZERELESI UTMUTATÁS
KEZELESI UTASÍTÁS


CZ MONTAZNI NAVOD
NAVOD K POUZITÍ






H-1,5 cm		H-5 cm					
							
A x4		B x2		C x6		D x2	





H-1,5 cm		H-5 cm			
					
A	x4	B	x2	C	x6
				D	x2






H-1,5 cm



A

x4

H-5 cm



B



C

x6



D

x2

